

БРЕНД	КОД МОДЕЛИ
ACSON	0234, 0468
ACTRON AIR	0573
AGER/AGREE	0489, 0785, 0107, 0108
AIRWELL	0529, 0555-0558
AITE	0002, 0012, 0292, 0326
AKIRA	0310, 0311
ALPIN	0252, 0253, 1788, 3325
AMCOR	0050, 0246, 0302, 0449
AMICO	0555-0558
ARENA	0206, 0212, 0229
ARISTON	0261, 0265
ARLEC	0202
AUCMA	0288-0296, 0302, 0462, 2337, 3534
AUSSIE AIR/ARD	0297, 0282, 0287
AUX	0297-0300, 0451, 0474, 0475, 0599, 2860, 3370
BANSHEN	0264, 1288, 3848
BLUESTAR	0261, 0265
BLUEWAY	0300
BOERKA	0383, 0434, 0436, 0437, 3967
BRIVAS	0107
CARRIER	0203-0209, 0235, 0456-0458, 0468, 0563-0565, 0590-0592
CELESTIAL	0307
CHANGHONG	0301-0308, 0046, 1325, 2353, 3982
CHANGLING	0002, 0012, 0119, 0191, 0192, 0261, 0298, 0369, 0630-0633
CHIGO	0379-0382, 0444-0447, 0489, 0515, 0610, 0261, 1916, 2940
CHOFU	0184-0187, 1721, 3771
CHUNLAN	0345-0350, 0450, 0453, 0545-0546, 3932
CLIMA VENETA	0572
CONIA	0297-0300, 0349, 0570, 0571
CONROWA	0377, 1913, 3961
CONSUL	0463, 0975, 2511
COOL PARTS GC	0416-0418, 0002, 0456
COOLINE	0187, 0206
CORONA	0155-0163, 0459, 2206
COUNTRY AIR	0560
DAEWOO	0203-0209, 0406, 2256, 3990
DAIKIN	0171-0183, 0468, 0472, 0566, 0567, 0574-0577, 0583, 2220, 3758
DEC/DHL	0504, 0592
DELONGHI	0232, 0482, 0484
DERBY/DIVINCHI	0311, 0289, 0400
DL	0302
DOCTOR	0221, 0449, 0499, 2497, 3850
DONGBAO	0219, 0355-0361, 2403, 3430
DONGXINBAO	0413, 2461, 3997
ELCO	0555-0558
ELECTRA	0555-0558
ELECTROLUX	0216-0220, 0268, 0300, 0534, 0569, 1753, 3802
EMAILAIR	0127-0135, 0553, 0556, 0558

БРЕНД	КОД МОДЕЛИ
FEDDERS	0498, 0499, 0500, 0528
FERROLI	0585
FRESTECH	0277, 0489, 0495-0497, 0519, 0520, 0534, 0048, 0261, 0448, 1813, 3349
FUJITA/FUJIAIRE	0265, 0297
FUJITSU	0127-0137, 0464, 0552-0554, 0118, 1158, 3720
FUNAI	0430, 0481, 1966, 3502
FUNAI/FUJIN	0430, 0481, 0802, 0942, 0002
GALANZ	0371, 0372, 0521, 0534, 1395, 2933, 3956
GE	0047
GEER	0002, 0012
GENERAL	0127-0137, 0464, 0552-0554, 0639, 1152, 2180, 3711
GLEE	0313, 2446, 3983
GOLDSTAR	0201, 0466-0469, 2515
GREE	0309-0316, 0398, 0399, 0482, 0490, 0512, 0513, 0591
GUQIAO	0244, 0291, 1268, 1827
HAIER	0266-0272, 0346, 0453-0455, 0538, 0539, 3852
HELLER HOFFWEL	0107, 0282, 0289, 0292, 0299
HICON(HUIKANG)	0016, 0368, 0441-0443, 0207, 2416, 3514
HISENSE	0332-0335, 0505-0506, 0517, 1869, 2895, 3917
HITACHI	0118-0126, 0605-0607, 1148, 2679, 3709
HOFFWELL	0811
HOMEMAKERS	0091, 0297-0300, 0451, 0810
HUABAO	0336-0344, 1879, 3409, 3926
HUAKE	0408, 1432, 2765, 3992
HUALING	0317-0325, 0452, 0207, 0234, 0261, 0523, 2500, 3906
HUAMEI	0402, 0460-0465, 1426, 1997, 1999, 3533
HUIFENG	0370, 0882, 2420, 3954
HYUNDAI	0012, 0202, 0297, 0345, 0433, 0466, 0480, 0555, 1226, 2250
JBS	0202, 0273
JDC	0373, 0440, 1397, 3000
JET-AIR/JBS	0169, 0202
JIANGNAN	0432, 1456
JIINDA	0414, 1950, 2536
JINSONG	0219, 0355, 0389-0391, 0446-0448, 3462
JOHNSON	0492, 0555-0558, 2028, 3829
KANGLI	0374, 0375, 2935, 3958
KELON	0282-0287, 0416-0418, 0473, 0485-0488, 0501, 0534
KELVINATOR	0151, 0197, 0203, 0107
KLIMATAIR	0225, 0226, 0452, 1988, 3810
KOLIN	0416-0418, 1952, 2465, 3539
KONKA	0397, 0457-0459, 2507, 3981
LENNOX	0017, 0260-0265, 0435, 0301
LEVANTE	0106
LG	0197-0200, 0514, 0534, 0572, 0634, 2050, 3730
LIANGYU	0233, 0451, 1257, 3523
LITTLE DUCK	0015-0020, 0527, 0530, 0532, 1556, 2070
LITTLE SWAN	0434, 0477, 0516, 0524, 0946, 1556

БРЕНД	КОД МОДЕЛИ
LOREN-SEBO	0255, 0471, 0472, 1496, 3543
LUXAIRE	0297
MCQUAY	0234-0237, 0465, 0468, 0472, 0567, 0587, 2283, 3820
MI A/C	0391
MICOM	0415, 1439, 2463
MIDEA	0260-0265, 0526, 1284, 2310
MISAKAE	0234-0237
MISTRAL	0237
MITSUBISHI	0001-0045, 0476-0479, 0522, 0523, 0552, 0553, 0568, 0582, 3628
NEC NATIONAL	0138-0154, 0200
NIKKO	0462, 0519
NISO	0013, 0016
NORITZ	0431, 1455, 2468
QGENERAL	0127-0137, 0464, 0552-0554
OMEGA	0559
OMNI	0146, 0262
PANASONIC	0138-0154, 0483, 0490-0492, 2019, 3738
NATIONAL	0138-0154, 0483, 0490-0492, 2019, 3738
PANDA	0378, 0890, 1405
PHILCO	0210, 0211, 0487, 0488, 3795
PILOT	0591
POLAR ICE	0571
PROTON	0421-0423, 2507, 3593
RAYBO	0362-0367, 1387, 2925
RHOSS	0484
ROWA	0369, 0438, 0439, 0494, 0527, 0531, 1975, 3510
SABRO	0435, 0506-0508, 2483, 3579
SACON	0002, 0288
SAIJO DENKI	0212-0215, 1238, 3285
SAMPO	0424-0426, 1448, 1961, 3497
SAMSUNG	0188-0196, 0516, 0518, 0700, 1726, 2239, 3772
SANYO	0046-0095, 0529, 0530, 0558, 0559, 1090, 3678
SAST	0002, 0012
SASUKI	0254, 0470, 2006, 3838
SENSOR	0046, 0071
SHANGLING	0384-0388, 0444, 0445, 3969
SHANXING	0392, 0449, 1416, 1985
SHARP	0096-0106, 0525, 0542, 1633, 2150, 2656
SHENGFENG	0376, 0480, 1504, 1912
SHINCO	0351-0354, 0454-0456, 2912
SHUAIKANG	0002, 0288, 0800, 1311
SHUANGLU	0376, 0404-0407, 0480, 3476
SKYWORTH	0359-0361, 3728, 3999
SONGGE	0428, 0429, 1965, 2988
SOVA	0409, 0410, 2457, 3482
STARIGHT-AIRCON	0283
STARWAY	0345-0350, 0450, 0453, 0545-0546
SUMMER	0427, 1963, 2485, 3499
SUNDURG	0257, 0505, 1793, 3841
SWAN	0434, 0477, 0516, 0524, 0946, 1556

БРЕНД	КОД МОДЕЛИ
TADIRAN	0246-0251, 0591, 2295, 3833
TATUNG	0419, 0420, 1955, 2979
TCL	0246, 0273-0281, 0468, 0476, 0493, 0534, 0570, 1299, 3347
TECO	0256, 0473-0475, 1280
TIANDI	0415, 0927, 1538, 3999
TIANDI, MICOM	0415, 0131, 0017
TITANIUM	0339
TOSHIBA	0107-0117, 0479, 0489, 0561, 0562, 1647, 3181
TOYO	0002, 0012
TRANE	0227-0232, 0512, 0595, 0739, 2276
UNI-AIR	0222-0224, 0450, 3522
VIDEOCON	0002, 0484
VOLTAS	0002, 0197, 0260, 0261, 0265, 0498
WANBAO	0138-0154, 0483, 0666, 0995, 1177
WEATHERMAKER	0203-0209, 0235, 0456-0458, 0468, 0482-0486, 0563-0565, 0590-0592
WEILI	0393-0396, 2442, 3979
WHIRLPOOL	0164-0170, 0481, 0489, 0502, 0505, 0506, 2038, 3752
WINIA	0481, 0550, 1505, 3553
XILENG	0411, 0412, 2460, 3995
XINLE	0297, 0298, 0400, 0401, 2960, 3985
YANGZI(YAIR)	0403, 1427, 3475
YINYAN	0258, 0259, 0330-0331, 0326-0331, 0478, 0303, 0364, 0381, 2888
YORK	0107, 0235, 0238-0243, 0468, 0501-0502, 0576, 0573, 0590-0592, 2287, 3312
YUETU	0002, 0534
ZHENBAO	0127-0137, 0464, 0639, 1164, 2176, 3200